

DOSE PUMPS

DECO Model

Low flow dose pump, very appropriate to dose many chemicals because the plastic materials involved

Characterized by the short stroke that assures a smaller wear.
Don't need maintenance

They are not damaged if work without liquid

Variable flow

230V 50Hz.



Main features

- ◆ ABS Box
- ◆ Stainless steel front cover.
- ◆ Polycarbonate cover for panel control
- ◆ Separation of electronic and hydraulics
- ◆ MOPLEN+FV pump head
- ◆ MOPLEN+FV valves
- ◆ Double sphere valve
- ◆ PTFE diaphragm of great thickness
- ◆ Brass piston
- ◆ Laterally adaptable.

Versions with PVC, PVDF or ST.ST. pump heads and valves, or special valves for viscous fluids

Code	Flow max	Pressure max	Stroke	CC x stroke	Volts / Watts	Kg.
1.9509.01	2 L/hour	8Kg/ cm ²	0,6m/m	0,3	220/30	4
1.9509.02	5 L/hour	5Kg/ cm ²	1m/m	0,9	220/30	4
1.9509.03	8 L/hour	2Kg/ cm ²	1.7m/m	1,32	220/30	4

Distribuidor: